

NVM 2 Version 1


OPERATOR'S MANUAL

V 0.1

7/30/2024



OPERATOR'S MANUAL



Warnings P. 1

**Equipment
Description** P. 2-3

NIGHT VISION MONOCULAR 2 VERSION 1 “BEACHVISION”

**Parts &
maintenance** P. 4-16

“NVM 2 v.1”

DISTRIBUTION STATEMENT NVM 2 - Distribution authorized by **WEST TEC LLC** or Hanssen Hassett. This publication is required for administration and operational purposes, as determined 30 July 2024. Other requests for this document shall be referred to either: Bob West, Brendan West, & Hanssen Hassett all by respective West Tec LLC emails & contact information: ...

DESTRUCTION NOTICE - For unclassified, limited documents, destroy by any method that will prevent disclosure of contents or reconstruction of the document.

WARNING

Do not carry batteries in pockets containing metal objects such as coins, keys, etc. Metal objects can cause the batteries to short circuit and become very hot.

WARNING

EQUIPMENT LIMITATIONS To avoid personal injury and property damage when using the NVM 2 carefully read and understand the following safety precautions.

- The NVM 2 requires some ambient (moonlight, starlight, or artificial light, etc.) to operate. The level of performance depends on the level of light.
- Night light is reduced by passing cloud cover, while operating under trees, in building shadows, etc.
- The NVM 2 is less effective viewing into shadows and other darkened areas.
- The NVM 2 is less effective through rain, fog, sleet, snow, smoke, and other reflective material. • The NVM 2 will not “see” through dense smoke.

Equipment Description

SYNOPSIS

The Night Vision Monocular 2, also known as the “beachvision” monocular is designed for use under low light & nighttime conditions within the vicinity of sea spray and moisture from salt water.

The NVM 2 is mounted via M5 bolt to a J arm or bridge night vision attachment. (e.g. pvs 14 J arm, PVS 28 bridge mount)

The NVM 2's most modern qualities derives from the addition of 3 new technologies:

1. interchangeable 32mm lens filters for both objective lens & eyepiece
2. 34mm diameter eyecup attachment capabilities
3. Focusable eyepiece

However the most important technology of the NVM 2 is its new ground up designed housing, completely different from its predecessor, it boasts sea spray resistance & threaded tube technology.

Equipment Description

Capabilities

The NVM 2 version 1 has a specially designed digital night vision housing made for the Runcam Night Eagle 3, & the adafruit 1.5" TFT display & PCB board.

Camera Specs (shortened)


Image Sensor	1/2.8"2MP
horizontal resolution	1500TVL
lens	16:9 Depth of field of view: 125° Horizontal: 107° Vertical: 56° Or 4:3 Depth of field of view: 97° Horizontal: 75° Vertical: 56°
signal system	NTSC/PAL switchable
Color	Black, White
net weight	8.5 grams

Image Specs (shortened)

Resolution	160 RGB x 240
------------	---------------


HOUSING DIAGRAM

The NVM 2 v. 1 housing consists of 8 parts



DETACHABLE PARTS

Only two ~~three~~ parts are interchangeable without invasive maintenance





The objective endcap & Female eyepiece Tube are removable via threaded tube

The eyepiece Cap can be unscrewed via the 3 Phillips Head 2 bolts

OBJECTIVE ENDCAP FUNCTIONS

The objective endcap is designed to be interchangeable with different Inside diameter objective endcaps for lens filters.

Objective
Endcap



Two different
endcaps (left)

Simply unscrew the
endcap with your
hands to remove, and
screw back in
replacement endcap,
**(do not over tighten,
you may damage
camera)**

EYEPIECE FUNCTIONS


The eyepiece is on a threaded tube allowing you to focus the eyepiece lens by turning the eyepiece with your hands.

To decrease distance from lens to display: Turn Clockwise

To increase distance from lens to display: Turn Counter-Clockwise


The Eyepiece extends out approx 5mm on a 34mm diameter tube. This tube is compatible with 34mm inner diameter rubber eyecups.

Simply slide rubber eyecups over tube to attach.





MAINTENANCE

The NVM 2 version 1's housing is designed to be air tight. The remaining parts of the housing that are not interchangeable/detachable are to be soldered together.





MAINTENANCE

Unfortunately the NVM 2 VERSION 1 is not suitable for maintenance. Due to the crude airtight nature of the design & with it being a prototype. However with the right tools, maintenance is possible



CAMERA MAINTENANCE

The Runcam Night Eagle 3 is placed inside of the “camera Housing” part. The Camera Housing part is a disc with a 19.25mm x 19.25mm box with one open end, and one half opened end, - centered within the disc.




Camera Housing
(Left)

CAMERA MAINTENANCE

POSSIBLE FAULTS:

1. **Lost Connection/no signal** (display still working)
2. **Broken by Endcap**
3. **Obscured by Endcap**

FOR NUMBER 1. Solder cut through Wire Housing, 4mm up away from Camera Tube. Cut all the way around circumference to detach wire housing from Camera Housing and tube...



CAMERA MAINTENANCE

FOR NUMBER 1. CONT...

Inspect that all wires are properly connected and insulated. And no wires are loose/not connected.




IMAGE LEFT
SHOWS PROPER
POWER
CONNECTION

If all wires are good, proceed with fingertips or needle nose pliers to press onto each connection. Sometimes a connection is poor and wires just need to be pressed together to touch. If fix, reglue those wires together to ensure proper connection.

If no fix, check with fingertips if the Runcam Night Eagle 3 is warm/hot, if so Camera is receiving power and issue is terminal or related to video connection to the display. See page 14 for Display Maintenance.

CAMERA MAINTENANCE

For Number 2

Unscrew Objective Endcap and look for visible damage or obstruction.

For Number 3

Unscrew Objective Endcap and look for visible damage or obstruction, test NVM 2 without the endcap.

Sometimes a lens filter on the endcap may be too dark. Or a small inner diameter endcap was creating a tunnel vision field of view and needs to be discarded


**NEVER OVERTIGHTEN OBJECTIVE
ENDCAP AS THIS MAY CRUSH THE
CAMERA!**

DISPLAY MAINTENANCE

POSSIBLE FAULTS:

1. **Lost Connection/no signal**
2. **Damaged/dead by Display**

For Number 1. Solder cut through Wire Housing, 4mm up away from Camera Tube. Cut all the way around circumference to detach wire housing from Camera Housing and tube. Then solder cut at cut line 2 where Display tube meets Wire Housing



DISPLAY MAINTENANCE

FOR NUMBER 1. CONT...

Inspect that all wires are properly connected and insulated. And no wires are loose/not connected.




IMAGE LEFT
SHOWS PROPER
POWER
CONNECTION


If all wires are good, proceed with fingertips or needle nose pliers to press onto each connection. Sometimes a connection is poor and wires just need to be pressed together to touch. If fix, reglue those wires together to ensure proper connection.

If no fix, check with fingertips if the Runcam Night Eagle 3 is warm/hot, if so Camera is receiving power and issue is related to video connection to the display.

DISPLAY MAINTENANCE

FOR NUMBER 1. CONT...

Ensure wires are tightly
Plugged into PCB, push in
With fingertips or needle nose
pliers



Check to see if
there are any
tears in the flex
connector

If torn, entire
display needs to
be replaced, or at
least flex
connector or
sourceable
standalone

If still no fix, check with page 11 for
camera maintenance. If still no fix
assume display is damaged and needs
replacement.

NVM 2 Version 1

OPERATOR'S MANUAL

V 0.1

7/30/2024

By Hanssen Hassett

SOMETHING WRONG WITH PUBLICATION



THEN...JOT DOWN THE
DOPE ABOUT IT ON THIS FORM.

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

Screenshot AND EMAIL TO:
WESTTECSUPPORT@...

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT PIN-POINT WHERE IT IS

IN THIS SPACE, TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT.

PAGE
NO.

PARA-
GRAPH

FIGURE
NO.

TABLE
NO.

PRINTED NAME, GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

1. The first part of the document discusses the importance of maintaining accurate records of all transactions and the role of the accounting department in ensuring the integrity of the financial statements. It emphasizes the need for transparency and accountability in all financial reporting.

2. The second part of the document outlines the various methods used to collect and analyze financial data, including the use of statistical models and the application of advanced data analysis techniques. It highlights the importance of using reliable data sources and the need for regular updates to the financial information.

3. The third part of the document provides a detailed overview of the financial performance of the company over the past year, including a breakdown of revenue, expenses, and profit. It also includes a comparison of the company's performance to industry benchmarks and a discussion of the factors that have contributed to the results.

4. The fourth part of the document discusses the various risks associated with financial reporting and the steps that have been taken to mitigate these risks. It includes a discussion of the importance of internal controls and the role of the audit committee in ensuring the accuracy of the financial statements.

5. The fifth part of the document provides a summary of the key findings of the financial review and offers recommendations for improving the company's financial performance. It includes a discussion of the importance of ongoing monitoring and the need for regular communication with stakeholders.